



FIBRE CEMENT FIXING DETAILS

Notes for Figure 11:

- **Concrete floor** bottom plate fixing:- Ramset bracing anchor kit Concrete or GIB Handibrac® with 15kN anchor at each end of bracing element
- **Timber floor** bottom plate fixing:- Ramset bracing anchor kit Wood or GIB Handibrac® with a 12x150mm galvanised coach screw at each end of bracing element
- **Edge Fixing Distance:** Hardie™ Flex Sheet, - minimum 12mm.
- **Overhang Distance:** Hardie™ Flex Sheet- 50mm

Product	System Number	Minimum Length
Hardie™ Flex Sheet	JHD	400 or 600mm