



Apply 6mm diameter adhesive sealant bead to the back of the 'T' socket before fixing over ExoTec® main Top Hat section. Continue bead onto back of Panel. Install Panel before sealant cures to ensure bond.