



Apply 6mm diameter adhesive sealant bead to the back of the 'T' socket before fixing over ExoTec® Top Hat section. Install Panel before sealant cures to ensure bond.