



**Note:** Horizontal packers must be set to a fall of 5° minimum where shown

***Note:** If studs are placed at 400mm centres no intermediate battens are required and nogs may be placed at max 1200mm centres. 100mm long packers will be required between battens as shown*