



Note: Ensure edges are well braced and timber braces are aligned over solid framing behind