



Notes

- Check architect's plans for the type of flashing to be used.
- Cut edges need to be primed.
- The flashing to be ideally placed in the centre of the floor joists.
- For further information about cavity barriers, refer to paragraph 5.8.5 of C/AS2 of the NZBC.