



Note: Notes:

- * Ensure that a continuous 6mm bead of adhesive sealant is applied between Hardie™ Axent™ Trim and Axon™ Panel.
- * Ensure that the required edge distance is maintained when fixing.
- * Seal cut edges with a primer compatible with final coatings.