



Note:

- * Ensure that a continuous 6mm bead of adhesive sealant is applied between Hardie™ CLD™ Structural Cavity Batten and Axon™ Panel.
- * Ensure that the required edge distance is maintained when fixing.
- * Seal cut edges with a primer compatible with final coatings.
- * Push panel hard against Hardie™ CLD™ Structural Cavity Batten.

For use ONLY where manufactured edge jointing not possible for build ie small window in full sheet