



Notes:

- This method is used to install full height sheets where the wall height is taller than the standard sheet height
- This jointing method **must not** be used at floor joists or gable ends as a control joint