

Note: When HomeRAB $^{\text{TM}}$ Pre-Cladding/ RAB $^{\text{TM}}$ Board is used flashing tape to be applied to the entire meterbox.