



Note:

- When HomeRAB™ Pre-Cladding/ RAB™ Board is used flashing tape to be applied to the entire window opening
- Sealant must be installed between Hardie™ Axent™ Trim and window flange in VH and EH wind zones and SED projects
- Alternatively, the head flashing can be formed with stop ends as per E2/AS1

jhl_axon24_u_024

jhl_axon24_u_ktaltd.rvt