



Note:

- * Check architect's plans for the type of flashing to be used.
- * Check fixing centres and edge distances.
- * Cut edges need to be primed with sealer.
- * When 50 year durability is required refer Table 20 E2/AS1.
- * The flashing to be placed in the centre of the floor joists. Do not fix Cavity Battens or panels into floor joists.