



Notes:
 Ensure edges are well braced and timber braces are aligned over solid framing behind

jhl_glaz_006