



Notes:
 This method requires the sheets to be fully braced temporarily while the adhesive cures.
 Bracing member should be aligned with the framing behind prefinished Lining.