



Notes:

1. Floor to be laid with two directional falls to corner waste. Perimeter edge of waste hole must be a minimum of 50mm from edge of sheet or wall. Build up falls around waste hole before applying waterproof membrane.
2. Tiles to be laid prior to HardieGlaze™ Lining installation.

jhl_glaz_042