



**Notes:**

1. Perimeter edge of waste hole must be a minimum of 50mm from edge of sheet or wall. Build up falls around waste hole before applying waterproof membrane.
2. Tiles to be laid prior to HardieGlaze™ Lining installation.

jhl\_glaz\_043