



- Note:
- When HomeRAB™ Pre-Cladding/ RAB™ Board is used flashing tape to be applied to the entire window opening
  - Sealant must be installed between head flashing and window flange in VH and EH wind zones and SED wind pressures
  - Alternatively, the head flashings can be formed with stop ends as per E2/AS1
  - Refer to Figure 22 for sealing end battens to head flashing