



**Note:**

1. Site cut edges to be primed
2. Sealant must be installed between head flashing and window flange in VH and above wind zones. Refer to Figure 71 of E2/AS1
3. When HomeRAB™ Pre-Cladding/RAB™ Board is used flashing tape to be applied to the entire window opening