



Note:

- Check architect's plans for the type of flashing to be used
- Cut edges need to be primed
- The flashing to be placed in the centre of the floor joists. Do not fix timber cavity battens or cladding into floor joists