



Notes:

- Take care to ensure continuous seal is formed between panel and the trimline joint
- Trimline horizontal Jointer will be required over the butt joint of the Hardie™ 14mm aluminium trimline joint
- Site cut edges to be primed
- Check architects plans for the type of flashing to be used
- Check fixing centres and edge distances
- When 50 year durability is required refer Table 20 E2/AS1
- The flashing to be placed in the centre of the floor joists. Do not fix cavity battens or cladding into floor joists