



Notes:

- Check architect's plans for the type of flashing to be used
- Check fixing centres and edge distances
- If top fixings are to be hidden by the Z flashing they will need to be fixed and sealed before the flashing is installed
- Cut edges need to be primed
- The flashing to be placed in the centre of the floor joists
- This detail is required to limit cavities to a maximum of 2 stories or 7 metres. Refer to E2/AS1 clause 9.1.9.4