

Window frame (refer to window manufacturer for method of support and fixing)

Packing block

Top edge and face of board at sill behind flashing to be primed

35 mm min cover
10 mm min.
5 mm gap

Sill flashing with 8mm turnup at each end and back of flashing. Seal joint at corners. Ensure the sill flashing does not slope backwards

Hardie™ Plank Weatherboard

Flexible underlay

For flashing tape detail refer to Figures 72 and 90 of the NZBC clause E2/AS1

Window liner

8 mm gap nominal

Watertight airseal as per E2/AS1 section 9.1.6

Window support packer

Selected interior lining

General note for materials selection

Flashing materials must be selected based on environmental exposure, refer to NZS 3604 and Table 20 of the NZBC E2/AS1