

Notes for Figure 36:

- **Timber floor** bottom plate fixing:- Ramset bracing anchor kit Wood or GIB Handibrac[®] with a 12x150mm galvanised coach screw at each end of bracing element

