



**Note:**

- When James Hardie rigid air barrier is used flashing tape to be applied to the entire window opening
- Alternatively, the head flashings can be formed with stop ends as per E2/AS1
- Sealant must be installed between Trim and window flange in VH and EH wind zones and SED pressures