



Note:
 1. Site cut edges to be primed
 2. Sealant must be installed between head flashing and window flange in VH and above wind zones. Refer to Figure 71 of E2/AS1