



Note:

- When James Hardie rigid air barrier is used flashing tape to be applied to the entire window opening
- Sealant must be installed between head flashing and window flange VH and EH wind zones and SED pressures
- Alternatively, the head flashings can be formed with stop ends as per E2/AS1

Plot Date: 17 Feb 2025 18:24

jhl_stri_r_021

jhl_stri.rvt