



- Sealant must be applied between head flashing and trim in VH and EH wind zones and SED wind pressures
- Site cut edges to be primed

jhl\_stri\_u\_037

jhl\_stri.rvt

June 2024  
Scale: 1 : 2